

Status Gruppe BMW Race Shift Knob Install Guide

This shift knob is made of delrin and is a tension fit part. To expand the knob for easy install you can use 2 methods.

1. Heat water to a boil and leave knob in for 5 minutes.
2. Use a heat gun or hair dryer to heat knob.

Use gloves or a towel to handle the now extremely hot shift knob. It should now slide right onto the factory shift rod.

For any questions please contact us via email (info@statusgruppe.com) or via phone #619-887-6006.

The Status Gruppe, INC.
statusgruppe.com